

AUTO - DIAL GSM BASED BURGLAR ALARM SYSTEM FOR HOME SECURITY

(Product Code : NS-ADBAS)



Auto - Dial GSM Based Burglar Alarm System For Home Security

(YOUR IDEAL SECURITY ALARM SYSTEM)

High Quality & Reliable + Easy Installation + No Expert Required + Burglarproof & Fireproof + Gas / LPG Leakage Protection + Emergency Help (SOS) + Branded Product with 1 Year Warranty

Branded Product with 1 Months Warranty

WE ARE ONLY A PHONE CALL AWAY CALL US

AT +91 - 9996635607

Whats in the Box

- Alarm System (Central Unit) 1pc.
- Wireless PIR Detector 1pc.
- Wireless Door (GAP) Sensor 1pc.
- Remote Controller 2pcs.
- Antenna 1pc.
- Mini Siren 110dB/0.3 m 1pc
- Power Supply 1pc.
- Users' Manual 1pc.

Product Description

This security alarm system consists of main panel/engine of alarm and various wireless-connected

accessories/sensors. If someone enters the defense region illegally, the main engine/panel will activate the loud siren and call the number stored in the main panel notifying the intrusion of the specific zone, so the person can take an immediate action. The system provides an option to monitor the scene form your mobile only.

Features

Long Distance Listen-in/arm/disarm Function

Intelligent Identification

Can be Triggered When Power Cable is Cut

Remote Control

Can Pre-Store 5 Groups of Alarm Phone Number

Can Add More Sensors If Needed

With Built-in Backup Battery in Case of Electricity Failure

NOTE: SIM card is not provided. You should buy SIM from your local mobile operator.

Verify your mobile operator supports GSM 900/1800 MHz frequencies.
Extremely Powerful Siren! Wear ear protection on initial siren test/install.

System Installation

Brief Introduction of System

This security alarm system consists of main panel/engine of alarm and various wireless-connected accessories/sensors. If someone enters the defense region illegally, the main engine/panel will activate the loud siren and call the number stored in the main panel notifying the intrusion of the specific zone, so the person can take an immediate action. The system provides an option to monitor the scene form your mobile only.

Alarm Installation

Insert the plug of telephone outside line into LINE2 of the main engine and connect LINE1 of the main engine with telephone using attached telephone wire of alarm. Then joint up the power source and warning signal; meanwhile the main engine will give a sound of "B" and light of the power source goes on, which means the main engine starts working.

Gate Magnetism Installation

Use the random equipped double-side tape to stick a magnetic stripe on the door and affix the gate magnetic

emission box on the doorframe. Pay attention to put the magnetic strip close to the side with indicator lights of the emission box during installation, assuring proper alignment and the smaller distance the better.

Infrared Detector Installation

The principle of infrared detectors is to sense people's movement through sensing infrared signals generated by bodies and the detection range is usually 5-12 meters. Infrared sensor should be installed about 2.2 meters away from ground. Aim straight at the detection ranges. Moreover, the infrared detector be only installed in the room, without facing the sunshine, windows and other places where temperature is easy to change, because the installed location may influence the detection range and accuracy.

GSM Card Installation

Pull SIM card cover behind the host, press SIM card socket with your fingers and push backward, then open the cover of card socket, insert SIM card into the cover based on the notch, keep the notched corner of SIM card in direction of that on board, depress the cover and move forward to lock SIM card.

Note:- Please do not buy if you don't know what it is, and how to use it.

Clear all doubts before purchase by Contacting Us!

Fast Shipping



We ship anywhere in India within 3 to 4 days after receiving payment
We ship internationally within 1 to 2 week after receiving pay

